








BIANCO BI-11-WB


- PL** Instrukcja montażu
- GB** Assembly instructions
- ES** Instrucciones de instalación
- FR** Instructions de montage
- CZ** Montážní návod
- D** Montageanleitung
- HU** Összeszerelési útmutató
- SK** Montážny návod
- RU** Инструкции по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- TR** Montaj talimati
- NL** Handleiding voor de montage
- UA** Інструкція монтажу




1






2




















3



4





- A1 - 2104x530 x 16 - x 1
- A2 - 2104x530 x 16 - x 1
- C - 416 x 516 x 16 - x 3
- F - 416 x 50 x 16 - x 2
- G - 2054x428 x 3 - x 1
- H - 2050x444 x 16 - x 1
- R - 409 - x 1

